

 POUND

# CHALLENGER

SUPER 16-BIT CONSOLE FOR SNES CARTRIDGES

## QUICK START GUIDE

v1.01



# HELLO AND THANK YOU!

For purchasing the Challenger 16-bit Entertainment System by Pound Technology! To get you set up quickly, please carefully read the instructions in this manual before enjoying the console.

For troubleshooting, please contact us at [hello@poundtechnology.com](mailto:hello@poundtechnology.com)

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## PACKAGE CONTENTS:

1. Composite Cables
2. USB to Micro USB cable
3. Challenger 16-bit Console
4. (2x) Challenger Controllers
5. AC Wall plug
6. HDMI Cable

1.



2.




3.




4.



5.



6.




# CHALLENGER LAYOUT



## FRONT:


1. Cartridge slot
2. Eject Button
3. Power Button
4. Reset Button
5. Player 1 Controller Slot
6. Player 2 Controller Slot



## REAR:

7. PAL/NTSC Toggle Switch
8. Composite Cable Ports
9. HDMI Port
10. Aspect Ratio Toggle Switch 4:3 or 16:9
11. Power port

# CHALLENGER SETUP



## INSTRUCTIONS:

1. Insert HDMI or composite cable into your television
2. Insert other end of the respective cable into the Challenger Console
3. Insert the AC adapter into the wall and plug the USB cable into it
4. Insert the micro USB end of the cable into the Challenger Console
5. Insert at least one controller into controller port labeled "1"
6. (optional) Insert second controller into port "2"
7. Insert game into cartridge slot
8. Select NTSC or PAL based on cartridge type
9. Select preferred aspect ratio (4:3 or 16:9)
10. Press the power button and enjoy retro bliss!